


- (CZ)** NÁVOD NA MONTÁŽ
- (DE)** MONTAGEANLEITUNG
- (PL)** INSTRUKCJA MONTAŻU
- (RU)** ИНСТРУКЦИЯ МОНТАЖА


- (GB)** INSTALATION INSTRUCTION
- (HU)** ÖSSZESZERELÉSI ÚTMUTATÓ
- (SK)** NÁVOD PRE MONTÁŽ
- (UA)** ІНСТРУКЦІЯ З МОНТАЖУ



X000001054



- | | |
|--------------------------------------|-------------------------|
| (CZ) POSTRANNÍ SKŘÍŇKA VYSOKÁ | NÁVOD NA MONTÁŽ |
| (DE) HOCHSCHRANK | MONTAGEANLEITUNG |
| (HU) OLDALSÓ SZEKRÉNY, MAGAS | ÖSSZESZERELÉSI ÚTMUTATÓ |
| (GB) SIDE CABINET, TALL | INSTALATION INSTRUCTION |
| (PL) SZAFKA BOCZNA WYSOKA | INSTRUKCJA MONTAŻU |
| (RU) ВЫСОКИЙ БОКОВОЙ ШКАФЧИК | ИНСТРУКЦИЯ МОНТАЖА |
| (SK) POSTRANNÁ SKRINKA VYSOKÁ | NÁVOD PRE MONTÁŽ |
| (UA) ШАФКА БОКОВА ВИСОКА | ІНСТРУКЦІЯ З МОНТАЖУ |



5

CZ/SK let záruky
 DE jahre garantie
 GB years of guarantee
 HU év garancia
 PL lat gwarancji
 RUS лет гарантии
 UA рокив гарантії



Ø10

L



R

